



Make your classrooms more collaborative



Airtame 2 is a device for streaming content wirelessly. Connect it to the HDMI port on your TV, projector or large format display, and share your screen from any device. No cables, no fuss, and teachers are no longer tethered to the front of the classroom. They can engage with their students, share presentation abilities, and unlock student-centered learning.




Mirror your screen from any device

You no longer have to juggle different types of input cables - Airtame 2 connects wirelessly to any device running on any platform. You can even connect your students' Chromebooks or mobile devices. Use AirPlay to connect your iPhone or iPad, and our app to show images and slides from your Android device.

Committed customer support

Whether you buy one or 100 Airtames, our Customer Success team is always on hand to help you find flow in your school.




Easy to deploy. Even easier to use

Airtame is easy to set up with your encrypted school WiFi network. Teachers and students can then connect directly with the Airtame app. It takes just two clicks for them to get going.


Digital Signage

Make your school stand out with customized screens. Display school notice boards, custom images, Google Slides or websites with Airtame.



Cloud management

Reduce your IT ticket requests with Airtame Cloud - an IT admin's dream. Easy remote management that lets you manage and monitor devices without leaving your chair.



PIN Code Connect

Keep in control. A new code is presented on screen every time you want to connect, meaning that connecting is quick, stable and safe.

Single Window Sharing

Just before you start screen sharing, you can select which individual window you want to present. You can keep working on your own screen while everyone keeps looking at your shared window.



Kensington lock support

Need to keep your Airtame 2 safe? Connect it to any standard Kensington lock.



System requirements

Minimum Dual core 1.6GHz CPU / 1GB RAM / WiFi: 802.11g / OS: Windows 7, Ubuntu 15.04, Mac OS X 10.9, iOS 9, Android 4.2.2

Recommended Computer from 2011 or newer Dual core 2.8GHz CPU 4GB RAM WiFi: 802.11 a / n / ac OS: Win 10, Ubuntu 15.04, Mac OS X 10.12, iOS 9, Android 4.2.2

Router recommendation 2.4 GHz n 5 GHz n / ac MIMO 2x2 300 MBit

More info @ airtame.com/is
Contact us at support@airtame.com to book a free demo call

Supports Windows, Mac OS, Chromebook, Linux, Airplay, Android*



*Using our native app