




D-I-G-I-T-A-L  
**PROMASTER**<sup>®</sup>

# Camera Grip

*Perfect for SLR's, Digital Cameras and Camcorders*

Attach the strap from the camera grip to the strap lug of your camera. Then attach the grip base plate to your camera. Adjust the strap to fit your hand comfortably.



PHOTOGRAPHIC RESEARCH ORGANIZATION, INC.  
FAIRFIELD, CT. 06825 [www.promaster.com](http://www.promaster.com)

*PROMASTER is a supplier of premium quality lenses,  
digital camera memory, batteries, accessories, filters, digital  
and conventional electronic flashes, camera cases and tripods.*

Made in Korea

Code7408